10寸国头明冀立扇(带脚轮)

HICFM

OWNER'S MANUAL

30" HEAVY DUTY PEDESTAL MISTING FAN

ITEM NO.: FAN-P30WM

120V / 60Hz, 2.0A

READ & SAVE THESE INSTRUCTIONS

Questions, problems, missing parts? Before returning the product,

please e-mail our customer service by

hicfm@outlook.com

READ AND SAVE THESE INSTRUCTIONS

1. To prevent serious injury or property damage read and understand owner's manual before operating.
2. This product can be used indoor or outdoor with a proper GFCI plug.

SAFETY INFORMATION

WARNING

1. Read and save these instructions. Do not operate fan unless you have read these instructions.
2. Unplug the fan before moving it or performing maintenance. Do not touch the fan when your hands are wet.
3. DO NOT have not qualified electricians should not disassemble, repair or rebuild the fan.
4. Unplug the fan when it is not in use.
5. DO NOT unplug the fan by pulling the cable cord. Unplug by holding the plug and pulling.
6. DO NOT use the fan when there is damage to the cable cord or plug. If the supply cord is damaged, it has to be replaced by the manufacturer, its service agent or similar qualified person.
7. To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer).
8. DO NOT use the fan close to fires.
9. DO NOT insert your hand or other objects into the grille or the movable parts.
10. To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
11. Do Not Use An Extension Cord With This Fan.

CAUTION

1. Unplug the fan from the socket and clean it with a soft cloth.
2. DO NOT immerse the fan.
3. Fit the guard onto fan before starting up the fan.
4. This fan is not intended for use by people (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the fan by a person responsible for their safety. Supervise children to ensure they do not play with the fan.

PACKAGE CONTENTS

Figure	Description	Quantity
1	Mounting Kit	1
2	Front Guard	1
3	Blades	1
4	Rear Guard	1
5	Motor	1
6	Extension Pipe	1
7	Oscillation Kit	1
8	Universal Base	1
9	Base	1

ASSEMBLY INSTRUCTION

1.Put the Wheels on Base, fasten them by M5*12 Screws, φ5 Star Washers and M5 Nuts.



ASSEMBLY INSTRUCTION

2. Through the bottom of base by M5*12 Screws and φ5 Star Washers, and fasten the Wheels with M5 Nuts.



3. Remove five Screws from base. Save them for step 4.

4. Attach Lower Pole to Base by tightening back the five Screws from Step 3.



ASSEMBLY INSTRUCTION

5. Loosen and remove the two screws (1) on the height adjusting knob on the upper connecting pole (2). Place the spring (3) into the standing pole (4). Insert the upper connecting pole (2) into the standing pole (4), making sure the holes on the height adjusting knob and the standing pole (4) are aligned. Insert the two screws (1) into the standing pole (4) and tighten them. Adjust the height of the upper connecting pole (2) as desired and secure using the adjusting knob.

6. Insert a bolt (5) into the hole on the neck bearing (found on the motor) and into the top of the upper connecting pole. Secure them together using a bushing (1) and a nut (2). Insert one bolt (6) through the hole in the neck bearing and into the top of the upper connecting pole and secure them a bushing (4) and a nut (3).

ASSEMBLY INSTRUCTION

7.Remove four sets of hexagonal nuts, spring washes, and bowl washers from the motor. Save them for step 8.

8.Attach the rear guard (4) to the screws found on the motor and secure them together using four bowl washers (1), four spring washers (2), and four nuts (3) from step 7.

9. Attach the blade (2) to the shaft on the motor and secure them together using two screws (1).

ASSEMBLY INSTRUCTION

10. Attach the front guard (1) to the rear guard (2) and secure them together using the clips on the front guard.



11. Secure the assembly on the front and rear guard by tightening the screw (1) and star washer (2) on the bottom of them and nut (3).



ASSEMBLY INSTRUCTION

12. Connect the misting switch (1) to the water pipe (2) and tighten it. Turn the switch (open) to open the misting function. Turn the switch (close) to close the misting function.

OSCILLATION INSTRUCTION

Turn the oscillation function on by pushing the oscillation button down.

OPERATION INSTRUCTION

1 Adjusting the fan tilt angle

- Ensure the fan is unplugged from the power source before/adjusting the tilt angle.
- Place the fan on a safe, flat surface where it cannot fall or be pulled by the cord.
- To adjust the angle of the fan head: Loosen the knob (1) to tilt the fan head (A) to the desired angle, and re-tighten the M6 hex nut (2).

2 Turning the fan On/Off and adjusting the airflow settings

- plug the fan into an electrical outlet.
- Adjust the desired speed by pulling the chain switch at the motor.

0 Stop 1 Low 2 Medium 3 High

Always turn off and unplug the fan after using.

Test GFCI (Ground Fault Circuit Interrupter) plug BEFORE EACH USE. Plug GFCI into power outlet. Press RESET button. Indicator should turn red. Press TEST button. Indicator should turn off. GFCI plug is tripped. Press RESET button again for use. DO NOT USE FAN IF ABOVE TEST FAILS. Call customer service for assistance.

CARE AND MAINTENANCE

Unplug the appliance before cleaning. Don't use any water for cleaning the appliance. Use a soft cloth to remove dust from the grille and the blades of the fan. In order to remove dust from the grill, use a vacuum cleaner or remove the front grill by removing the securing screws on the edge of the grill. After cleaning, remount the grill. After doing this, fasten the screws on the edge of the grill.

1-YEAR LIMITED WARRANTY

The manufacturer warrants this product to be free from manufacturing defects in the material and workmanship under normal use for a period of one year after the date of purchase by the original purchaser.

This warranty does not cover transit damages. This warranty does not apply to damages from accident, misuse, alteration of any kind to the fan or where the connected voltage is more than above the nameplate voltage. This warranty does not apply to the finish on any portion of the product. Servicing performed by unauthorized persons or using unauthorized replacement parts is not responsible for damages of any kind, including accident and consequential damages. Some states do not allow the exclusion or limitation of the incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

REPLACEMENT PARTS LIST

PART	DESCRIPTION	PART #
1	Blade	FAN-P30WM