

INSTALLATION:

1. Kit installs on door stop. Measure distance between threshold and top of door along door stop. Cut both long strips to length. Cut with hacksaw or scissors.
2. With door closed place one long strip on door stop along hinge side. Install with fasteners so vinyl bulb compresses against door. Install other long strip on latch side. (It will be necessary to drill pilot holes in steel door frames.)
3. Cut short strip and install along top door stop so it fits snugly against strips mounted on sides to prevent leakage at corners. Install with fasteners included.



QUESTIONS? | PREGUNTAS?
800.654.8454
MDBUILDINGPRODUCTS.COM

