



# SPILL KIT USER GUIDE

SK010M. For use by trained employees.

## Materials:

- 20 Gal / 75 L Salvage Drum
- 2lb / 1kg Loose Sorbent
- 2qty 3in x 24in / 8cm x 60cm Socks
- 3qty 3in x 48in / 8cm x 120cm Socks
- 4qty 10in x 10in / 25cm x 25cm Pillows
- 4qty 12in x 12in / 30cm x 30cm Pillows
- 5qty Absorbent Mats
- 5 x Disposable Bags



## 1 Risk assessment

Identify the source of the spill, the type material spilled and the volume. Make sure that unauthorized personnel have left the site and that there are no flammables near. For serious spills, contact the local authorities.

## 2 Personal Protective Equipment

Put on gloves and safety goggles.

## 4 Stop a potential spread

Use socks or booms at the forward edge of the spill to avoid the fluids to spread. Make a barrier with a sock or boom at nearby drains. If oil has reach any drains, contact the local authority.

## 5 Stop the leak

Rotate the damaged drum, close valves or plug the source to prevent more liquid to spill.

## 6 Pillows, mats and loose sorbent

Use the Green Boom absorbent pillows and mats to soak up the oil. Finish with the loose sorbent.

## 7 Disposal

Dispose the materials in accordance with local laws.

## 8 Prepare and Prevent

Clean the used PPE for safe reuse and restock the absorbents. Review the cleanup procedures and report the incident to keep accurate records for improved prevention in the future.

**For any questions, reach out to your Green Boom representative. Find instructional videos and more information on our website: [greenboom.com](https://www.greenboom.com)**