



# WIPE NEW® WIPE-IT® CLOTHS

## DESCRIPTION AND USES

For smaller jobs and one-time use needs, we offer single use Wipe-It® Cloths. These are microfiber cloths pre-saturated with Wipe New® and sealed in single-use foil packets. Wipe New Wipe-It Cloths are safe and effective to use on plastic, rubber, vinyl, and acrylic surfaces. Wipe New Wipe-It Cloths not only restores the original sheen to faded trim, it protects most surfaces from harsh elements that eventually wear away that showroom new appearance. Wipe New's unique formula works like no other to restore your vehicle's trim in one quick, easy application and protect it with a durable finish that will last for years.

## PRODUCT FEATURES AND BENEFITS

- Ceramic protection
- Protects from oxidation and fading
- Provides UV protection
- No silicone or oils

## PRODUCT

SKU	DESCRIPTION
WI120YCASE	Wipe New 120pk Trim Wipes Packet

## PRODUCT APPLICATION

**READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING PROJECT**

**DO NOT APPLY WIPE NEW WIPE-IT CLOTHS TO ANY PAINTED SURFACES, INCLUDING THE BODY OF A VEHICLE. WIPE NEW WIPE-IT CLOTHS ARE NOT INTENDED FOR USE ON PAINTED SURFACES AND MAY DAMAGE THOSE SURFACES.**

### IMPORTANT NOTES:

- When applying Wipe New Wipe-It Cloths, wear nitrile gloves and always use in a well ventilated area. If applying to a vehicle interior, roll windows down before beginning.
- Wipe New is not intended for use on paint, glass or mirrored surfaces. If applying near windows, roll them down or tape them off before you begin to prevent contact with the glass
- Use the Prep Wipe to clean the surface prior to Wipe New Trim Restore application.
- Let Wipe New Wipe-It Cloths dry for 1 hour before touching the treated surface.
- Plan to work from the highest point of your surface down to the lowest. This helps to keep freshly coated surfaces from being touched before they are dry.
- Allow 24 hours for full cure before exposing treated surface to moisture (rain, dew, sprinklers, car wash, etc). Exposure to moisture before full cure can result in streaking or spotting on the surface.

## PRODUCT APPLICATION (cont.)

### IMPORTANT NOTES (cont.)

- Do not apply Wipe New Wipe-It Cloths to hot surfaces or in direct sunlight. After washing and drying vehicle, move it to a shaded area and allow the surface to cool to ambient temperature. Application to a hot surface may cause the surface to appear streaked.
- If Wipe New Wipe-It Cloths come in contact with an unintended surface such as paint, wipe it off immediately with a dry cloth. Within an hour of application (while still undergoing initial cure), Acetone may be used to remove Wipe New from a painted surface, but not from plastic or any non-metal surface. Because Acetone can damage vehicle parts or paint, it should be used only after checking with the vehicle manufacturer or a Certified Paint Professional as to how to best apply or remove product. After Wipe New has cured, removing it will require the use of a fine polishing compound or high grit automotive sandpaper.
- If the pre-saturated Wipe-It Cloth begins to dry out, discard and open a new Wipe-It Cloth. Continuing with a dry Wipe-It Cloth may result in streaking on the surface.
- Store Wipe New Wipe-It Cloths in a cool dry place and discard within one year of purchase.

### APPLICATION

**IMPORTANT:** Before you start, test Wipe New Wipe-It Cloths on an inconspicuous spot to ensure the result is desirable as it will vary by material and surface damage.

1) Tear open pre-saturated Prep Wipe and clean surface prior to product application. Clean thoroughly to ensure residues from any pre-existing restorative products are completely removed. If the surface is heavily soiled, wash the surface to be treated with liquid dish detergent or car wash (free of wax, moisturizers or other additives) before using the Prep Wipe. Rinse and dry thoroughly.

**IMPORTANT:** Ensure that no water remains on or around the surface to be treated. Dry with a towel or chamois and let the surface air dry for at least 15 minutes. Open trunk and car doors and dry any excess water.

2) Tear open pre-saturated Wipe-It.

3) Apply in a single wipe to the intended surface with little or no overlap, from one row to the next, until the surface is completely coated.

4) Discard the applicator cloth when the application is finished or if it begins to dry during application.

**NOTE:** For badly faded and/or extremely porous surfaces, a 2nd coat may be required for optimal results. If applicable, allow the first coat to dry for a minimum of 5, up to a maximum of 10, minutes then immediately repeat steps 3 through 5.

	<b>TECHNICAL DATA</b>	<b>WNW-30</b>
<b>WIPE NEW® WIPE-IT® CLOTHS</b>		

**PHYSICAL PROPERTIES**

		WIPE-IT CLOTHS
<b>Resin Type</b>		Siloxane Polymer
<b>Pigment Type</b>		NA
<b>Solvents</b>		N-Butyl Acetate and Parachlorobenzotrifluoride
<b>Volatile Organic Compounds</b>		None
<b>Practical Coverage at Recommended DFT</b>		Coverage may vary depending on material and wear
<b>Dry Times at 70-80°F (21-27°C) and 50% Relative Humidity</b>	<b>Touch</b>	1 hour
	<b>Recoat</b>	15 minutes
	<b>Full Cure</b>	24 hours
<b>Shelf Life</b>		5 years
<b>Flash Point</b>		92°F (32°C)
<b>Safety Information</b>		For additional information, see SDS

Calculated values are shown and may vary slightly from the actual manufactured material.

The technical data and suggestions for use contained herein are correct to the best of our knowledge, and offered in good faith. The statements of this literature do not constitute a warranty, express, or implied, as to the performance of these products. As conditions and use of our materials are beyond our control, we can guarantee these products only to conform to our standards of quality, and our liability, if any, will be limited to replacement of defective materials. All technical information is subject to change without notice.