

INSTALLATION INSTRUCTIONS FOR RUBBER FLOORING

Brava Foam Rubber Tiles are DIY and install in minutes

Wall-to-wall Installation

1. Start in one corner of the room with a Brava corner tile (with both border edges attached) leaving a ¼" gap away from the wall for expansion and contraction over time.
2. Add Brava border tiles (with one border edge attached) outward along the adjacent walls.
3. Continue to add border tiles and inside tiles (with no edges attached) where you see fit.
4. When coming up to an opposite walls, cut the tiles to fit the area leaving a ¼" gap away from the walls.

Area Rug (free floating) installation

1. Start with one Brava corner tile (with both border edges attached)
2. Add Brava border tiles (with one border edge attached) outward from the corner tile along the adjacent sides.
3. Continue to add corner tiles, border tiles and inside tiles (with no edges attached) where you see fit.

Note: Adhesives are usually not used since the weight of the interlocked tiles together is usually enough to keep the floor tiles from moving. You can use some double-sided carpet tape to prevent any movement where necessary.