

Reference Guide

Seaming of Rigid Sheet Material

Please read all instructions before installing sheet material

Seaming Rigid Sheet Material using a Vertical Divider Bar



Step 1: First measure the size of the vertical divider bar you need.



Step 2: Cut vertical divider bar with utility knife



Step 3: Slip the divider bar onto the rigid sheet



Step 4: Installer Tip! Use small amounts of painter's tape to set the vertical divider bar in place prior to adhesion



Step 5: Adhere sheet with divider bar to wall.



Step 6: Use roller to secure sheet and vertical divider bar piece to adhesive

Reference Guide

Seaming of Rigid Sheet Material

Please read all instructions before installing sheet material

Seaming Rigid Sheet Material using Vinyl Seal – Color Matched Caulk



Step 1: Adhere sheet to wall leaving the width of a penny ($\frac{1}{16}$ " or 1.59mm) between sheets.



Step 2: Apply painters tape exactly to edges of sheet



Step 3: Apply painters tape to top cap to protect the sheet from the color-matched caulk.



Step 4: Use caulk gun to apply color-matched caulk



Step 5: Use putty knife to scrape off excess color-matched caulk



Step 6: Immediately remove tape (if it dries, the caulk will come off with the tape)



Step 7: Finished seam shown

© 2012 InPro Corporation