



1. Open the carton box and take out the tool cabinet, should be carefully
2. Remove the lock bar, open the door, remove the top cabinet and plate.
3. Remove the accessory box from the drawer.
4. Put down the cabinet on the floor and mounting Wheels. It is recommended to install two brake wheels on the same side, two universal wheels on the same side, and use an open-end wrench to fix the wheels.
5. Stand up the tool cabinet and use 5 pcs M6 * 9 screws to secure the plate.
6. Take out 2 pcs M6*9 screws to fix the part box on the side.
7. Install the door handle with the M6*4 screw
8. Put the top cabinet on the below cabinet. Then you can use it normally.

Parts drawing	Part name	Quantity
	top cabinet	1
	below cabinet	1
	Parts box	1
	Plate	1
	wheels	4
	wrench	1
	Phillips screws M6*9	7
	Phillips screws M4*6	1
	handle	1