



READY SEAL® EXTERIOR WOOD STAIN WITH TURBO SPRAY SYSTEM™

DESCRIPTION AND USES

Ready Seal® Exterior Wood Stain with Turbo Spray System™ seals and protects exterior wood from the damaging effects of water and UV light. The powerful oil-based technology protects and beautifies in one coat.

Use Exterior Wood Stain with Turbo Spray System on exterior wood surfaces, including decks, fences, lattice, and furniture.

NOTE: Surfaces previously sealed with Ready Seal Exterior Wood Stain may be resealed with this product. No need to strip or remove previous coat.

PRODUCT FEATURES

- Powerful oil-based technology protects and beautifies in one coat
- No Laps, No Runs, No Streaks®
- No back brushing required
- No cracking, chipping, flaking or peeling
- Easy Maintenance - no sanding or stripping required for reapplication
- Ideal for small projects

PRODUCT

SKU	DESCRIPTION (22.5 oz. Aerosol)
401752	Natural
401753	Pecan
401754	Dark Walnut
401755	Natural Cedar
401756	Redwood
401757	Mahogany
401758	Burnt Hickory
401759	Mission Brown

PRODUCT APPLICATION

READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING PROJECT

SURFACE PREPARATION

Proper surface preparation is critical to achieve best results. Prepare the surface with a deck stripper and/or a deck brightener based on wood condition described below.

After preparation, conduct a Splash Test on bare wood (described below) to confirm water absorption before applying this product.

PRODUCT APPLICATION (cont.)

SURFACE PREPARATION (cont.)

PREVIOUSLY COATED, WEATHERED WOOD

For best results, previous coatings such as paints, solid color and semi-transparent stains, transparent stains, toners, or clear sealers in a weathered state, should be stripped to create a bare, sound surface for maximum coating adhesion and durability. To remove previous coatings, stains, or sealers, use an appropriate stripping product.

Thoroughly clean with a deck brightener to remove chalky paint residue, embedded dirt, mildew and other contaminants, residual coating material and water repellents. Select the appropriate cleaning product for your wood type, use according to directions and rinse with a power washer for best results. When dry, scrape off and sand any remaining loose flaking or peeling coating using 50 or 60 grit sandpaper. After wood is dry, conduct a splash test (described below).

UNCOATED, WEATHERED WOOD

Before staining, bare, weathered wood must be thoroughly cleaned to remove ground-in dirt, mildew, mold and algae stains, gray, UV damaged wood fibers, and any other surface contaminants. According to label guidelines, select the appropriate product for your particular wood type; then follow usage directions on the label, rinse and let dry. After wood is dry, conduct a Splash Test (described below).

UNCOATED, NEW WOOD

Unlike other water-based sealers that require wood to be weathered for months, Ready Seal Stain & Sealer can be applied immediately to newly installed wood to stop rain and other precipitation from damaging wood. If new wood is Cedar or Redwood, "mill glaze" on the surface is a common condition. Eliminate these barriers by using a deck cleaner or brightener. Select the appropriate product for your particular wood type, follow usage directions on label, rinse and let dry. After wood is dry, conduct a Splash Test (described below).

PERFORM A SPLASH TEST

To conduct a Splash Test, sprinkle several handfuls of water on a few distinct areas of the bare wood surface. If the water absorbs rapidly, the surface is ready to be coated. If the water beads, puddles or is not absorbed, an internal or external barrier exists, and must be eliminated before staining can begin. Repeat using a stripper and/or cleaner and conduct splash test again.



READY SEAL® EXTERIOR WOOD STAIN WITH TURBO SPRAY SYSTEM™

PRODUCT APPLICATION (cont.)

SURFACE PREPARATION (cont.)

Houses painted before 1978 may contain lead. **WARNING!** If you scrape, sand, or remove old paint from any surface, you may release lead paint dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

APPLICATION

Use outdoors or in a well-ventilated area such as an open garage. Use when temperature is between 50°F (10°C) and 90°F (32°C) and humidity is below 85% to ensure proper drying. Do not apply in direct sunlight. Do not apply if rain is expected within 24 hours. Avoid spraying in very windy, dusty conditions. Cover plants, shrubs, and additional surrounding areas to protect from spray mist.

Shake can vigorously for one minute after mixing ball begins to rattle. If mixing ball fails to rattle DO NOT STRIKE. Contact Rust-Oleum. Shake often during use. Hold can upright 12"-20" from surface and spray in a steady back-and-forth motion, slightly overlapping each stroke. Make sure surface is completely coated for color uniformity. Keep the can the same distance from the surface. Keep the can in motion while spraying to avoid pooling. If heavy runs or drips occur, back brush or wipe off, if desired, for a more uniform look.

NOTE: The closer the can is held to the surface the faster you should move the can while spraying to avoid drips and sags. Occasional touch-up or recoat may be necessary for areas subject to heavy foot traffic and/or extreme UV exposure.

PRODUCT APPLICATION (cont.)

COVERAGE

Each can covers up to 50 square feet (single coat). Actual coverage will vary depending on the porosity of the surface.

DRY & RECOAT TIMES

Dry times are based on 70°F (21°C) and 50% relative humidity. Dries the touch in 1 hour. Recoat, if necessary, any time after 1 hour. On decks, allow to dry 24 hours before light foot traffic and 48 hours before replacing furniture or heavy foot traffic. If the surface is tacky or soft, extend the drying time before putting heavy objects back in place. Full cure will take approximately 7 days. Avoid dragging furniture across the surface. On newly stained surfaces, allow 7 days for the coating to cure before washing.

CAUTION: BARE WOOD OR COATED SURFACES CAN BECOME SLIPPERY WHEN WET. Use caution when walking on wet surfaces.

CLEAN-UP

To clear spray for future use, turn can upside down and spray until gas is emitted. Wipe off tip before storing. Clean up with lacquer thinner or xylene. Protect unused product from freezing. Throw away empty can in trash pickup. Do not burn or place in home trash compactor.

	TECHNICAL DATA	RSL-02
	READY SEAL® EXTERIOR WOOD STAIN WITH TURBO SPRAY SYSTEM™	

PHYSICAL PROPERTIES

EXTERIOR WOOD STAIN WITH TURBO SPRAY SYSTEM		
Resin Type		Alkyd
Pigment		Inorganic
MIR		0.90 max
Fill Weight		22.5 oz.
Practical Coverage		Up to 50 sq. ft./can (single coat) Coverage will vary depending on surface porosity, wood type, and texture
Dry Times @ 77° F (25°C) and 50% Relative Humidity	Touch	1 hour
	Handle	1 hour
	Recoat	1 hour
	Full Cure	7 days
Flash Point		-141°F (-96°C)
Shelf Life		3 years
Safety Information		For additional information, see SDS

Calculated values are shown and may vary from the actual manufactured material.

The technical data and suggestions for use contained herein are correct to the best of our knowledge, and offered in good faith. The statements of this literature do not constitute a warranty, express, or implied, as to the performance of these products. As conditions and use of our materials are beyond our control, we can guarantee these products only to conform to our standards of quality, and our liability, if any, will be limited to replacement of defective materials. All technical information is subject to change without notice.



Rust-Oleum Corporation
11 Hawthorn Parkway
Vernon Hills, Illinois 60061

Phone: 800-323-7357
www.rustoleum.com

Form: EJ-337
Rev.: 121825