
TILE INSTALLING MACHINE



Instruction Book

Parameter:

Batter Capacity: 21V/12V LI-ion-2.0AH

Charging Current:1A

Charging time: 2H

Suction power: 30KGS

Notes:

1. The machine must be stored in dry place.

2. Remove any dirt or dust from the surface of the machine after use.

3. Store the machine in the carry case supplied to avoid damage.

4. During frequent use it is recommended to recharge the machine daily. It is also advisable to recharge it at least once a month if not used for long periods of time.

Usage:

1. Assembly the battery pack

2. Hold down the no/off button to switch ON the machine.

3. Press shortly the on/off button to adjust vibration:

-level 1: Red (Min.)

-level 2: Red and Yellow (Med.)

-level 3: Red, Yellow and Green (Max)

4. At level 3, hold down on/off button to switch OFF the machine.

5. Red light on/off flashing, means battery is at low level, recharge the battery.