

EdenDirect

20-inch Pedestal Fan

INSTRUCTION MANUAL



MODEL: SY20

110 V / 60 Hz 165 W

PLEASE READ AND SAVE THESE INSTRUCTIONS

Questions, problems, missing parts? Before returning the product, please e-mail our customer service by service@edendirect-brand.com

Specifications

Model	Voltage (V)	Frequency (Hz)	Power (W)	Speed settings	Phase
SY20	110	60	165	5	Single

Operating instructions

- Before inserting the Power plug into a electrical outlet, check if the voltage and frequency on the rating label match the local power supply.
- Speed Control: Turn the speed control knob to select one of 5 speeds.




FIGURE 1

For the stand type installation, please refer to Figure 1. First, fit the stand column onto the base and secure it with screws (Note: There are two types of connecting structures between the base and stand column. Please install according to the actual product structure as shown in Figure 1). Then, attach the fan motor to the top of the stand column using screws (No. 10). The grill and blade should be installed as shown in Figure 1.

Maintenance

Safety First

1. Always unplug the fan before cleaning or performing any maintenance.
2. Never attempt maintenance while the unit is plugged in or operating.
3. Periodically inspect the power cord, plug, and all screws for damage or looseness. Do not use the fan if any part is worn or broken.

Cleaning

1. Use a soft cloth dampened with mild soapy water. Wipe dry immediately.
2. Do not use alcohol, engine oil, or other organic solvents.
3. Do not bend or press the fan blades—even slight deformation can cause imbalance, noise, or unsafe operation.
4. A light wax polish may be applied to the exterior surfaces only.

Precautions

Power Supply: The power socket used must be properly grounded. Use the fan only with a grounded outlet. It is recommended to install a main power switch with a contact gap greater than 3mm in the supply circuit.

Voltage & Frequency: Ensure the power supply voltage and frequency match the specifications on the product nameplate.

Power Disconnection: Always disconnect the fan from the power supply before moving, cleaning, or repairing it.

Electrical Safety: This is a Class I appliance. Do not modify the original wiring or rewire the plug.

Operation Safety: Do not insert the power cord or any objects into the fan grill while the fan is running to prevent blade damage and personal injury.

Intended User: This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Usage Environment: Do not use this fan in areas with corrosive gases, excessive dust, steam, or flammable gases.

Repairs: If the product malfunctions, take it to an authorized service center for repair. Do not attempt to repair it yourself to avoid mechanical or electrical hazards.

Thermal Fuse: A thermal fuse is attached to the motor winding. If it blows due to an abnormal condition, it must be replaced by authorized service personnel according to specifications to restore normal operation.


Power Cord: The power cord uses a Y-type connection. If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

Long-term Storage: When not using the fan for an extended period, please unplug it from the power outlet.

Thanks for choose the Edendirect brand and purchase our quality products!

If our products or services can satisfy you, we sincerely hope that you will choose Edendirect brand again and leave a good review. This can inspire our hearts! It is also the motivation for us to continue to move forward!

5 star rating



Edendirect will continue to improve the quality of its products and efficient services to provide an easy shopping experience for every customer!

We provide one-year warranty, if you have any problem when you receive the product or during use, please feel free contact email: service@edendirect-brand.com. We hope you will give us the opportunity to help you, and we sincerely thank all of our customers for taking time to research this product and give us valuable suggestions and feedbacks!

*Thank you so much
for your support!!!*



Please read this manual before operating and save it for future reference.

Every fan covered with a 1-year free warranty offered by **Edendirect** that is automatically valid from the date of purchase.

If you have any problem, please email us at **service@edendirect-brand.com**