



Add extraction to your Square Lite with the HydroVac Pro!
HydroVac Pro - SS HPS18
 • 2 Gallon Solution Tank - Delivers the right amount of water or chemical for thorough cleaning.
 • 2.5 Gallon Recovery Tank - Collects dirty solution with ease, keeping your workspace clean and dry.
 • 24" Squeegee - Provides wide coverage for faster, streak-free recovery. **Not for chemical stripping, dry stripping or sanding.**

Maintenance Schedule

- Prior to use (daily)**
 - Check AC power cord. DO NOT operate equipment if AC power cord is cut, frayed, or if ground is missing.
 - Check grip face and driver pad. Inspect for wear/debris.
 - Clean excess build-up on machine and between the driver plate and machine base.
- After use (daily)**
 - Clean pad and base plate assembly. Remove or replace pad as needed.
 - Inspect grip face for wear. Remove debris between grip face and base plate.
 - Wipe entire unit with a damp microfiber cloth.
 - Make certain a pad is placed on the grip face.
- Weekly Preventative Maintenance**
 - Check grip face for wear.
 - Use a vacuum to clean away debris build-up around base plate.
- Annually**
 - Replace ALL isolators.
 - Bearing assembly should be replaced as needed. Replace isolators when replacing the bearing.

Quick Start Guide

Scan the QR code to learn more



**SQUARE
SCRUB**

196 CR 702
 Jonesboro, AR 72405
 800-557-6822
 squarescrub.com

The owners manual QR code can also be found on the motor of the Pivot.



1 QUICK START GUIDE
Square Lite



Make certain a pad is between the grip face and the floor.

2



Determine what pad to use. Tilt the machine back and place on top.

3




Adjust the height of the handle using the lever at the base of the handle.

4



Plug in the power cord.

5



Squeeze the handle trigger on either side to operate the Square Lite.

6



Replace dirty pad after use with a clean driver pad and wipe down the machine.



Shop Pads



Blue Tile & Grout



Blue Driver



White Driver




Red Driver



Microfiber



Carpet



Clean LVT



Clean Tile & Grout



Clean Concrete