




SL50551 / SL50552


FAUX LEATHER CLUB CHAIR

FAUX LEATHER LOVESEAT

OPERATING INSTRUCTIONS



SL50551



SL50552

WARNING

1. Use this product for the intended amount of people only.
2. Do not use this product unless all screws & bolts are securely tightened.
3. Check that all screws are tight every three months or as needed.
4. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
5. Do not use chair as a stepladder.
6. Use this product for its intended purpose only.

OSP FURNITURE LIMITED PRODUCT WARRANTY

Reception, Wood Guest and Lounge Seating

- 5 years structural integrity of frame
- 3 years on seating wood finishes
- 3 years on upholstery fabric and Foam against wear and deterioration (except leather)
- Leather is not warranted against routine scratching and scuffing, as leather is subject to minor blemishes in use. Minor variations in color, texture and grain are a natural part of leather hides, and therefore, are not covered by this warranty.
- C.O.M. Fabrics are not warranted by Office Star Products

**All warranties are limited to the original purchaser for normal commercial usage defined as a standard forty hour work week by persons weighing 250 lbs. or less. This warranty will not cover labor, freight or damage from misuse, abuse, negligence, alteration, accident, vandalism, rusting, acts of nature or any other event beyond the control of Office Star Products. The warranty does not cover cosmetic damage that may result from normal use. Liability for incidental or consequential damages is excluded. The user assumes all risk of injury resulting from use of this product. When usage is more than 40 hours per week, a two year warranty on all parts applies. Fabric and foam is warranted for one year. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.*

It is the customer's responsibility to prepay freight on any components returned to the factory. Return freight on components covered by warranty will be paid by Office Star Products.

Our quality standards are among the highest in the industry. Sometimes, no matter how hard we try, there are times when parts are damaged or missing. Our Parts Department will do everything possible to promptly remedy the problem. Contact us via e-mail parts@officestar.net, by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 5:00 p.m. Pacific Time.


SL50551 / SL50552

FAUX LEATHER CLUB CHAIR


FAUX LEATHER LOVESEAT

OPERATING INSTRUCTIONS


STEP 1



STEP 2



STEP 3



PART	QTY
1. Chair Body.....	1
2. Back Cushion	1
3. Leg.	4

Remove all parts from carton, separate by part numbers indicated on parts list, and verify part quantities.

STEP 1 Screw Legs (3) into bottom of Chair Body (1). **FULLY TIGHTEN ALL LEGS (3).**

STEP 2 Slightly teeter Back Cushion (2) and slide down between arms of Chair Body (1). Partially interlock one bracket of Back Cushion (2) to adjacent bracket of Chair Body (1), **SEE DETAIL A. DO NOT FULLY INTERLOCK BRACKETS.**

STEP 3 Compress arms of Chair Body (1) firmly to partially interlock brackets on other side of Back Cushion (2). Once all four brackets are aligned, apply firm downward pressure on Back Cushion (2) to fully interlock brackets, **SEE DETAIL B.**

ATTENTION: MAKE SURE ALL LEGS ARE FULLY TIGHTENED BEFORE USING CHAIR.