


HICFM

OWNER'S MANUAL

30" HEAVY DUTY PEDESTAL FAN



ITEM NO.: FAN-P30W

120V / 60Hz, 2.4A

READ & SAVE THESE INSTRUCTIONS

Questions, problems, missing parts? Before returning the product,

please e-mail our customer service by

hicfm@outlook.com

SAFETY INFORMATION

WARNING

1. Read and save these instructions. Do not operate fan unless you have read these instructions.
2. Unplug the fan before moving it or performing maintenance. Do not touch the fan when your hands are wet.
3. Those who are not qualified electricians should not disassemble, repair or rebuild the fan.
4. Unplug the fan when it is not in use.
5. DO NOT unplug the fan by pulling the cable cord. Unplug by holding the plug and pulling.
6. DO NOT use the fan when there is damage to the cable cord or plug. If the supply cord is damaged, it has to be replaced by the manufacturer, its service agent or similarly qualified persons.
7. To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer).
8. DO NOT use the fan close to fires.
9. DO NOT insert your hand or other objects into the grille or the movable parts.
10. To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
11. DO NOT use this fan outdoors, this fan is designed for indoor use only.
12. To Reduce The Risk Of Fire Or Electric Shock Do Not Use With An Extension Cord.

CAUTION

1. Unplug the fan from the socket and clean it with a soft cloth.
2. DO NOT immerse the fan.
3. Fit the guard onto fan before starting up the fan.
4. This fan is not intended for use by people (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the fan by a person responsible for their safety. Supervise children to ensure they do not play with the fan.

PACKAGE CONTENTS





Figure	Description	Quantity
1	Front Guard	1
2	Blades	1
3	Screws	4
4	Rear Guard	1
5	Motor	1
6	Fan Head Knob	1
7	Extension Pipe	1
8	Shock Absorbent Spring	1
9	Lower Pole	1
10	Screws	5
11	Wheels	2
12	Base	1


ASSEMBLY INSTRUCTION



Step 1
Put the Wheels on Base, fasten them by M5*12 Screws, ϕ 5 Star Washers and M5 Nuts.

Step 2
Through the bottom of base by M5*12 Screws and, ϕ 5 Star Washers, and fasten the Wheels with M5 Nuts.


ASSEMBLY INSTRUCTION



Step 3
Remove five Screws from Base. Save them for Step 4.

Step 4
Attach Lower Pole to Base by tightening back the five Screws from Step 3.


Step 5
Insert the Shock Absorbent Spring into the Lower Pole as shown in the picture.




Step 6
Make sure the Black Ring must be located at the bottom side of the Extension Pipe.

Step 7
Remove two Screws on Black Ring around Extension pipe. Save them for Step 8

ASSEMBLY INSTRUCTION



Step 8
Insert Extension Pipe into Lower Pole. Fix Black Ring onto Lower Pole by tightening back two screws from Step 7. Adjust Extension Pipe to your desired height and secure it by tightening back the Height Adjust Knob.
WARNING: To avoid injury and prevent from cutting, never put your head over the Extension Pipe during or before the Extension Pipe was secured onto the Lower Pole tightly.




Step 9
Fasten two pieces of brackets with motor by 2 screws and washers. The screws and washers stocked in the motor box.

Step 10
Mount the fan head onto the extension pipe by tightening the screws, washer and nuts. The screws, washer and nuts stocked in the motor box.

Step 11
Remove four sets of Hexagonal Nuts, Spring Washers and Bowl Washers from motor. Save them for Step 12.


ASSEMBLY INSTRUCTION



Step 12
Set Rear Guard in proper position, and fix it to Motor by securing back the Hexagonal Nuts, Spring Washers and Bowl Washers from Step 11.

Step 13
Remove two screws from Motor Shaft. Save them for Step 14.


Step 14
Assemble Fan Blades onto Motor Shaft by tightening two screws from step 11. Make sure the screws are tightly secured.



Step 15
Assemble Front Guard to Rear Guard by fixing both Guards together with Clips on the rim of Front Guard.

Step 16
Secure the assembly of Front Guard and Rear Guard by tightening a screw, star washers and nut on the bottom position of them.


OSCILLATION INSTRUCTION



Position A – To make the fan head oscillate
To make the fan head oscillate: loosen the screw and move the position A. Tighten it back. Note: the screw is preset at position A at the factory.

Position B – To stop the fan head oscillate
To stop the fan head oscillate: loosen the screw and move to position B. Tighten it back. Caution: Switch off the fan before adjusting fan head oscillation.

OPERATION INSTRUCTION



CARE AND MAINTENANCE


Unplug the appliance before cleaning. Don't use any water for cleaning metal surfaces. Slightly moisten a cloth and then wipe off the surfaces of the fan. In order to remove dust from the grill, use a vacuum cleaner or remove the front grill by removing the securing screws on the edge of the grill. After cleaning, remount the grill. After doing this, fasten the screws on the edge of the grill.

1-YEAR LIMITED WARRANTY

The manufacturer warrants this product to be free from manufacturing defects in the material and workmanship under normal use for a period of one year after the date of purchase by the original purchaser.

This warranty does not cover transit damages. This warranty does not apply to damages from accident, misuse, alteration of any kind to the fan or where the connected voltage is more than above the nameplate voltage. This warranty does not apply to the finish on any portion of the product. Servicing performed by unauthorized persons shall render the warranty invalid. The warranty is not responsible for damages of any kind, including accident and consequential damages. Some states do not allow the exclusion or limitation of the incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

REPLACEMENT PARTS LIST



PART	DESCRIPTION	PART #
1	Blade	FAN-P30W