

# REED

## Model R9800

### Digital Scale



## Instruction Manual

[www.reedinstruments.com](http://www.reedinstruments.com)

# Table of Contents

Safety .....	2
Features.....	3
Specifications .....	3
Operating Instructions.....	4-5
Auto shut off.....	5

## Safety

To ensure that you get the optimal performance of your scale please adhere to the following guidelines:

- Please ensure the scale is placed on a clean and leveled surface before each use.
- Never place an item that exceeds the total capacity of 5000 g or 9 lbs 15 oz on this unit. If this does occur, the screen will show an error message “-----”. Doing this may damage the scale immediately and placing a weight in excess of scale capacity on the platform is not covered under warranty.
- Let the scale acclimatize to room temperature before using in order to allow the internal components to stabilize.

## Features

- Large LCD display
- Quick response with high accuracy
- Stainless steel platform
- User selectable grams and ounces
- Full tare capacity
- Low battery and overload indicator

## Specifications


Capacity	5000g / 9lbs / 15oz
Resolution	0.1oz / 1g (min 0.2oz / 2g start)
Display	LCD, 55 x 21 mm
Units	g / lbs / oz
Tare	Yes
Auto off	Yes
Auto zero	Yes
Low battery indicator	Yes
Over load indicator	Yes
Power	2 x AAA batteries
Platform size	8.3 x 5.9 x 0.5" (210 x 150 x 12 mm)
Certification	CE

## Operating Instructions

*Insert 2 x "AAA" batteries into the scale*

## Power on

Press  button to turn on the scale, “88888” will display on the screen. When “0 oz” appears the scale is ready to use.



## Measure weight

Place the items to be measured in the middle of the stainless steel platform, the weight value will go up quickly and display on the screen.



## Tare

Place an empty plate on the platform if needed, then when the weight value is steady, press the  button to set the scale's zero point.



## Change the measurement unit weight

The default measurement is in oz/lb. You can change the measurement value to g by pressing the  button. (Note: if the rate of gram to libra is very small, and the weight is too light, lb will show 0).



## Auto shut off:

Unit will automatically shut off after 2 minutes of idle use.



For service on this or any other REED product or information on other REED products, contact REED Instruments at [info@reedinstruments.com](mailto:info@reedinstruments.com).





