

AK5-JB...

Diagram illustrating the assembly of the AK5-JB... component, showing various parts and their installation steps.

Parts and Labels:

- AF1-EA6
- AM1-PA
- AM1-EC
- AF1-CD6
- AF1-CD 061
- AM1-ED
- AF1-CF 56
- AM1-DL201

Dimensions and Specifications:

- 2 x 6 x 14
- 2 x M6 x 16
- 2 Ø 6.5 mm
- 2 Ø 0.25"
- Ø 6.5 mm
- Ø 0.25"
- 6 N.m
- 53 lb in

Assembly Steps:

- Install AF1-EA6 and AM1-PA.
- Install AM1-EC and AF1-CD6.
- Install AF1-CD 061 (Note: This step is marked with a red X, indicating it is not to be done).
- Install AM1-ED and AF1-CF 56.
- Install AM1-DL201.


Table of Dimensions:


	L
AK5 JB 143	330
AK5 JB 144	438
AK5 JB 145	546
AK5 JB 146	654
AK5 JB 149	978
AK5 JB 1410	1086

Click!



	L
AK5 JB 143	330
AK5 JB 144	438
AK5 JB 145	546
AK5 JB 146	654
AK5 JB 149	978
AK5 JB 1410	1086

AK5-JB...


	 DZ5-C			
min	2,5 mm ² , AWG 14	-	2,5 mm ² , AWG 14 36 mm ² , AWG 2	10 mm ² , AWG 8
max	1 x 50 mm ² 1 x AWG 1	2 x 36 mm ² 2 x AWG 2	35 mm ² , AWG 2 36 mm ² , AWG 2	70 mm ² , AWG 2/0
	2 x 16 mm ² 2 x AWG 6			2 x 16 mm ² 2 x AWG 6




AK5-PC●●●



AK5-PC...



AK5-PC...



AK5-PA...

