

# MAASDAM POW'R-PULL®

## Fence Tool Instructions

### #8050-10 WIRE GRIP



Capacity: 1/2 Ton

Recommended for: Barb Wire Fence or Chain Link Fence

Purpose: Tie-off of wire

Use with: Maasdam Pow'R-Pull

1. Open Wire Grip spring cam and insert wire through cam. (Caution: When working with barbed wire always use heavy leather gloves.)
2. Leave necessary length of wire extending from cam in order to accomplish tie-off.
3. Hook fixed end of Maasdam Pow'R-Pull to a stationary object per written instructions in Maasdam's Operations and Safety Manual.
4. Hook the cable end of the Pow'R-Pull to wire grip eyelet, making sure safety latch is securely closed.
5. Operate Pow'R-Pull to tighten wire. Refer to Maasdam's Operations and Safety Manual for complete operating instructions.
6. Tie off wire.
7. Release Pow'R-Pull per instructions found in Maasdam's Operations and Safety Manual.
8. Remove wire from Wire Grip by depressing spring loaded cam.






### #8035-10 FENCE PULL CHAIN

Recommended for: Chain Link Fence

Purpose: Tightening span of chain link fence


Use with: Maasdam Pow'R-Pull

1. Attach both grab hooks onto draw bar. Where appropriate, one hook can be used.
2. Adjust chain to insure proper pull. Adjustments can be made using one or both grab hook adjusters and/or the adjustable pull plate.
3. Hook fixed end of Maasdam Pow'R-Pull to a stationary object per written instructions in Maasdam's Operations and Safety Manual.
4. Hook the cable end of the Maasdam Pow'R-Pull to adjustable pull plate, making sure safety latch is securely closed.
5. Tighten fence using Pow'R-Pull. Refer to Maasdam's Operations and Safety Manual for complete operating instructions. CAUTION: Over tightening may result in damage to fence.
6. Bracket draw bar to fence post.
7. Release Pow'R-Pull per instructions found in Maasdam's Operations and Safety Manual.



### #8060 FENCE STRETCH'R™

1. Remove clevis pin and cotter key.
2. Adjust the handle pin for pole size and replace clevis pin and cotter key.
3. Place Fence Stretch'R cradle around pole.
4. Hook curved piece over draw bar.
5. Pull fence until handle locks.
6. Install retaining clamp to draw bar.
7. Remove Fence Stretch'R!



## MAASDAM POW'R-PULL

- 1 piece, aluminum alloy ratchet wheel
- High strength, electro-plated steel parts
- "Notch-at-a-time" let down
- Non-slip plastic grip
- OSHA recommended safety latches
- Uses galvanized, aircraft quality cable
- Drop forged steel slip hooks

**⚠ WARNING:** This product can expose you to di(2-ethylhexyl) phthalate (DEHP), which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

Mailing: 415 East State Parkway, Schaumburg, IL 60173 • Telephone: 888.797.7855 • Fax: 847.228.6021