

Missing Parts? Assembly Questions?

Call us at 1-866-816-3822 or email help@regencyof.com for immediate assistance.

ASSEMBLY INSTRUCTIONS

REGENCY

RGS

FURNITURE

LCTRT7135XX




Legacy 71" Racetrack Conference Table
with Power Data Grommet

CT-CTRT7135XX





Cornerstone 71" Racetrack Conference Table
with Power Data Grommet



Parts:



Hardware:



IMPORTANT NOTICE:

Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
Check to be sure that you have all parts and hardware.
Remove all wrapping materials, including staples & packing straps before you start to assemble.
Keep all hardware parts and packaging out of reach of children.
Two person assembly recommended.

Missing Parts? Assembly Questions?

Call us at 1-866-816-3822 or email help@regencyof.com for immediate assistance.

ASSEMBLY INSTRUCTIONS:



LCTRT7135XX

Legacy 71" Racetrack Conference Table
with Power Data Grommet


CT-CTRT7135XX

Cornerstone 71" Racetrack Conference Table
with Power Data Grommet


Step 1: Insert (3) Cam Pins (F) into each Leg (C). Two go on the inside, and one on the outside.



Step 2: Attach Stringer (B) to Legs (C) by lining up Cam Pins (F) with Cam Locks on Stringer (B). Secure into place and tighten Cam Locks.



Step 3: Attach Supports (D) to outside of both Legs (C) by lining up the Cam Pin (F) with the Cam Lock on Support (D). Drop into place and tighten Cam Locks.



Missing Parts? Assembly Questions?

Call us at 1-866-816-3822 or email help@regencyof.com for immediate assistance.

ASSEMBLY INSTRUCTIONS:


LCTRT7135XX

Legacy 71" Racetrack Conference Table
with Power Data Grommet

CT-CTRT7135XX


Cornerstone 71" Racetrack Conference Table
with Power Data Grommet

Step 4: Place both Table Tops (A) face down on a clean, carpeted surface and insert (4) Cam Pins (F) into each Top (A).




Step 5a: Push both Table Tops (A) together, and secure with Sash Locks—Rotate handle into the “ON” position until it locks into place.


Step 5b: Attach Flat Brackets (H) between Table Tops (A) using (4) Screws (E) per Flat Bracket (H)



Step 6: Using two people, move the assembled base onto the Table Tops (A), lining up each Cam Pin (F) on the Table Top (A) with a Cam Lock on the base. Tighten all Cam Locks once base is in position



Step 7A: Attach Corner Brackets (G) using (4) Screws (E) each where Table Top (A) & Stringer (B) meet.



OPTIONAL STEP 7B: Cover Cam Locks using Cam Covers (I).

Missing Parts? Assembly Questions?

Call us at 1-866-816-3822 or email help@regencyof.com for immediate assistance.

ASSEMBLY INSTRUCTIONS:

LCTRT7135XX

Legacy 71" Racetrack Conference Table
with Power Data Grommet

CT-CTRT7135XX

Cornerstone 71" Racetrack Conference Table
with Power Data Grommet

Step 8a: With two people, carefully flip assembled table over and set upright



Step 8b: Insert DPEL (J) into precut hole and attach using (2) Screws (E).

