



## **Adjustable Mud Flaps**

### **OWNER'S MANUAL**



#### **WARNING:**

Read carefully and understand all **ASSEMBLY AND OPERATION INSTRUCTIONS** before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

**Model # TTF-242425AMF**

Thank you very much for choosing this product! For future reference, please complete the owner's record below:

Model: \_\_\_\_\_ Purchase Date: \_\_\_\_\_

Save the receipt, warranty and these instructions. It is important that you read the entire manual to become familiar with this product before you begin using it.

This product is designed for certain applications only. The manufacturer cannot be responsible for issues arising from modification. We strongly recommend this product not be modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the product until you have first contacted us to determine if it can or should be performed on the product.

For technical questions please call **1-218-943-6296**.

## INTENDED USE

Adjustable Mud Flaps.

## TECHNICAL SPECIFICATIONS

Item	Description
Mud Flap Size	24" wide x 24" high
Adjustment	Height: 16" - 22"      Width: 72" – 86"
Receiver Size	2.5"

## GENERAL SAFETY RULES



**WARNING:** Read and understand all instructions. Failure to follow all instructions listed below may result in serious injury.



**CAUTION:** Do not allow persons to operate or assemble the Mud Flaps until they have read this manual and have developed a thorough understanding of how the Mud Flaps work.



**WARNING:** The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

## SAVE THESE INSTRUCTIONS

## WORK AREA

- **Keep work area clean**, free of clutter and well lit. Cluttered and dark work areas can cause accidents.
- **Keep children and bystanders** away while operating the Mud Flaps. Distractions can cause you to lose control, so visitors should remain at a safe distance from the work area.
- **Be alert of your surroundings.** Using Mud Flaps in confined work areas may put you dangerously close to cutting tools and rotating parts.

## PERSONAL SAFETY

- **Stay alert**, watch what you are doing and use common sense when using the Mud Flaps. Do not use Mud Flaps while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating a may result in serious personal injury.
- **Dress properly.** Do not wear loose clothing, dangling objects, or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.
- **Use safety apparel and equipment.** Use safety goggles or safety glasses with side shields which comply with current national standards, or when needed, a face shield. Use a dust mask if working in dusty work conditions. This applies to all persons in the work area. Also use non-skid safety shoes, hardhat, heavy-duty gloves, dust collection systems, and hearing protection when appropriate.

## Mud Flaps USE AND CARE

- **Do not modify the Mud Flaps in any way.** Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the Mud Flaps was designed.
- **Always check for damaged or worn out parts before using the Mud Flaps.** Broken parts will affect the Mud Flaps operation. Replace or repair damaged or worn parts immediately.
- **Adjust Mud Flaps 2” off the ground.**
- **Can be cut to desired length. New bolt holes will need to be drilled.**


## ASSEMBLY

1. Attach upside block (#17) and downside block (#18) to the ball mount with screw (#16) tightly.
2. Install downside block (#18) and main frame (#20) with washer (#13), spring washer (#14), and bolt (#15). Adjust height as needed.
3. Insert left frame (#2) and right frame (#19) into main frame (#20) with nut (#12), bolt (#11), and screw (#16) tightly. Adjust width as needed.
4. If rubber mud flaps are too long, cut to desired length and re-drill holes.  
**Never use if parts are loose or damaged.**

## MAINTENANCE

- **Maintain your Mud Flaps.** It is recommended that the general condition of any Mud Flaps be examined before they are used. Keep your Mud Flaps in good repair by adopting a program of conscientious repair and maintenance. If any abnormal vibrations or noise occurs, have the problem corrected before further use. Have necessary repairs made by qualified service personnel.

# DIAGRAM & PARTS LIST



Part#	Description	Qty.	Part#	Description	Qty.
1	End Cap	4	11	Bolt M10X50	4
2	Left Frame	1	12	Nut M10	4
3	Plate	2	13	Washer M10	4
4	Nut M8	8	14	Spring Washer M10	4
5	Bolt M8X30	8	15	Bolt M10X55	4
6	Mud Flap	2	16	Screw M10X30	4
7	Nut M5	16	17	Upside Block	1
8	Washer M5	16	18	Downside Block	1
9	Logo Plate	2	19	Right Frame	1
10	Screw M5X16	16	20	Main Frame	1

For replacement parts and technical questions, please call **1-218-943-6296**.

## WARRANTY

**One-year limited parts warranty**



Tow Tuff  
 PO BOX 203  
 Miliona, MN 56354  
 MADE IN CHINA