

# ADJUSTABLE TRUCK BED EXTENDER

## OWNER'S MANUAL



### **WARNING:**

Read carefully and understand all **ASSEMBLY AND OPERATION INSTRUCTIONS** before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Thank you very much for choosing the Product! For future reference, please complete the owner's record below:

Model: \_\_\_\_\_ Purchase Date: \_\_\_\_\_

Save the receipt, warranty and these instructions. It is important that you read the entire manual to become familiar with this product before you begin using it.

This machine is designed for certain applications only. The distributor cannot be responsible for issues arising from modification. We strongly recommend this machine not be modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the machine until you have first contacted the distributor to determine if it can or should be performed on the product.

## TECHNICAL SPECIFICATIONS

**Maximum Weight Capacity:** 350 lbs. (159kg)

**Hitch extension Bar:** 39in. (99cm)

**Crossbar width with 3 positions:** 48in. (122cm), 60in. (152cm) and 72in. (183cm)

**5 height adjustments:** From 15in. (38cm) - 22in. (56cm) up from the hitch, at 1 3/4in. (4.4cm) increments

### Intended Use

The Truck Bed Extender supports loads that are 3 feet longer than the truck bed, making it easy to transport longer items such as ladders, small boats, drywall, and more.

Fits any truck with Class III receiver hitch.

Can be easily removed and stored in the truck cab.

The Truck Bed Extender includes tie-down loops.

## GENERAL SAFETY RULES



**WARNING:** Read and understand all instructions. Failure to follow all instructions listed below may result in serious injury.



**CAUTION:** Do not allow persons to operate or assemble this Truck Bed Extender until they have read this manual and have developed a thorough understanding of how the Truck Bed Extender works.



**WARNING:** The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

# SAVE THESE INSTRUCTIONS

## WORK AREA

- **Keep work area clean**, free of clutter and well lit. Cluttered and dark work areas can cause accidents.
- **Keep children and bystanders** away while operating a Truck Bed Extender. Distractions can cause you to lose control, so visitors should remain at a safe distance from the work area.
- **Be aware of all power lines, electrical circuits**, water pipes and other mechanical hazards in your work area, particularly those hazards below the work surface hidden from the operator's view that may be unintentionally contacted and may cause personal harm or property damage.
- **Be alert of your surroundings**. Using a Truck Bed Extender in confined work areas may put you dangerously close to cutting tools and rotating parts.

## PERSONAL SAFETY

- **Stay alert**, watch what you are doing and use common sense when using a Truck Bed Extender. Do not use a Truck Bed Extender while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating a Truck Bed Extender may result in serious personal injury.
- **Dress properly**. Do not wear loose clothing, dangling objects, or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.
- **Use safety apparel and equipment**. Use safety goggles or safety glasses with side shields which comply with current national standards, or when needed, a face shield. Use as dust mask in dusty work conditions. This applies to all persons in the work area. Also use non-skid safety shoes, hardhat, gloves, dust collection systems, and hearing protection when appropriate.

## TRUCK BED EXTENDER USE AND CARE

- **Do not allow anyone to climb upon or stand on the extender**.
- **Do not modify the Truck Bed Extender in any way**. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the Truck Bed Extender was designed.
- **Always check of damaged or worn out parts before using the Truck Bed Extender**. Broken parts will affect the Truck Bed Extender operation. Replace or repair damaged or worn parts immediately.
- **Do not exceed the Truck Bed Extender load capacity**.
- **Distribute the load evenly**. Uneven loads may cause the Truck Bed Extender to tip, resulting in personal injury to the operator or others.
- **Use the Truck Bed Extender on flat and level surfaces** capable of supporting the Truck Bed Extender and its maximum load. Pulling or pushing a load on a slanted or uneven surface can result in loss of control.
- **Store idle Truck Bed Extender**. When Truck Bed Extender is not in use, store it in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.
- **The maximum load capacity for the Truck Bed Extender is 350 lbs**. Do not exceed this weight capacity.

- **Only use the Truck Bed Extender with a Class III truck receiver hitch.** Do not modify the Truck Bed Extender in any way.
- **Before each use, check all hardware for tightness** and make sure that both L-pins and both R-clips are correctly in place.
- **Always use tie-down loops to properly secure** the extended load (with proper fasteners, not included) and use warning signs (not included) to alert other vehicles

## **ASSEMBLY**


Place all parts on the work surface and refer to the part number listing and parts diagram shown below.

1. Assemble the Extension Tube (#2) into Cross Bar (#1) and secure with L-Pin (#4) and R-Clip (#5). There are 3 width adjustment positions on extension tube making the width of cross bar at 48in., 60in. and 72in..
2. Assemble the Cross Bar (#1) into Hitch Extension Bar (#3) and secure with L-Pin (#4) and R-Clip (#5). There are 5 height adjustment positions on Cross bar (#3) making the height from 15in.–22in. up from the hitch.
3. Slide the long end of the Extension Bar (#3) into the Class III Receiver Hitch and secure with L-Pin (#4) and R-Clip (#5)
4. The Truck Bed Extender is now ready for use.

## **MAINTENANCE**

- **Maintain your Truck Bed Extender.** It is recommended that the general condition of any Truck Bed Extender be examined before it is used. Keep your Truck Bed Extender in good repair by adopting a program of conscientious repair and maintenance. If any abnormal vibrations or noise occurs, have the problem corrected before further use. Have necessary repairs made by qualified service personnel.

# DIAGRAM & PARTS LIST



## Parts List

Part	Description	Qty
1	Cross Bar	1
2	Extension Tube	2
3	Hitch Extension Bar	1
4	L-Pin	4
5	R-Clip	4

## WARRANTY

90days limited warranty