



AC power adapter for touchless faucet K-R31498

Features

- For use with KOHLER touchless kitchen faucets.
- Eliminates the need for batteries.

Installation

- Easily connects to power box for fast and simple installation.
- 120 volt unswitched power source required.
- Intended for use in North American outlets only.

Recommended Products/Accessories

K-R77748-SD Touchless pull-down kitchen sink faucet
K-R22898-SD touchless pull-down kitchen faucet
K-R32323-SD Touchless pull-down kitchen faucet
K-REC32323-SD Touchless pull-down kitchen faucet




Codes/Standards

UL 1310

KOHLER® Faucet Lifetime Limited Warranty

See website for detailed warranty information.



Technical Information

All product dimensions are nominal.

Installation Type: Surface-mount

Material: Plastic

Notes

Install this product according to the installation instructions.