

# Assembly Instructions


ReadySpace Storage System  
Model No. 30536, 98536, 30553

Instrucciones de Ensamble  
Akro-Mils ReadySpace Storage System  
Ejemplar No. 30536, 98536, 30553

Instructions d'assemblage  
Akro-Mils ReadySpace Storage System  
Le modele No. 30536, 98536, 30553

## Wall Unit 30536


Parts - piezas - pièces



x1




x2 or 3  
(not included/  
no incluye/  
non-includes)




x1


1



2




3




## Single or Double-Sided Bench Unit 98536


Parts - piezas - pièces



x1




x2





x2




1



Single-Sided



## Floor Unit 30553



### Leveling Feet 30553LF for Floor Unit 30553 (optional/opcional/facultatif)

#### Parts - piezas - pièces:

- 4 leveling feet
- 4 hex nuts packed in 7" x 12" mailer

1/4" and 1/2" open end wrench  
(not included/no include/non-includes)

