


**SEAT HEIGHT**  
Turn to raise  
and lower seat.  
Pull handle out for  
tilt movement.  
Push in to lock  
tilt movement.

**TILT TENSION**  
Turn knob to  
adjust tension.



**SEAT HEIGHT**  
Turn to raise  
and lower seat.  
Pull handle out for  
tilt movement.  
Push in to lock  
tilt movement.

**TILT TENSION**  
Turn knob to  
adjust tension.