

Please read and save these instructions. Read through this owner's manual carefully before using product. Protect yourself and others by observing all safety information, warnings, and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property. Please retain instructions for future reference.



ROLLING CABINET

Description

The Westward rolling cabinet has a durable red finish and strong load capacity. The cabinet is equipped with full extension ball bearing slides, ensuring smooth functionality of all drawers, and chrome-plated side carrying handles. Each drawer can hold up to 66 lbs(30kg). The cabinet is ideal for mechanics, craftsmen, repairmen and garage owners interested in storing and organizing tools and parts.

Unpacking

When unpacking, please ensure the unit is upright. Do not use any sharp objects to open the packaging.

After unpacking unit, inspect carefully for any damage that may have occurred during transit. Check for loose, missing, or damaged parts. Any shipping damage claim must be filed with the carrier.



Specifications and Dimensions

Model	Type	Casters	No. of Drawers	Dimensions (Inches)		
				Width	Depth	Height
32H882	Light Duty	4"×2"PP CASTERS	3	26.69"(678MM)	18.07"(459MM)	27.64"(702MM)
32H883	Light Duty	4"×2"PP CASTERS	5	26.69"(678MM)	18.07"(459MM)	27.64"(702MM)
32H884	Light Duty	5"×2"PP CASTERS	10	41.02"(1042MM)	18.07"(459MM)	33.82"(859MM)
32H851	Light Duty	5"×2"PP CASTERS	11	55.12"(1400MM)	18.07"(459MM)	33.82"(859MM)

General Safety Information

⚠ CAUTION

Ensure the drawers are closed and locked completely before moving the cabinet.

Handle and swivel casters must be attached on the same side of the product.

Keep the product on level surfaces. The product may become unstable and tip if stored or moved on an un-level surface, which may cause personal injury or product damage.

⚠ WARNING

Do not alter the product in any manner. Do not step or climb on the cabinet.

Do not open more than one drawer at the same time. The cabinet may become unstable and tip.

Please ensure the cabinet is locked prior to moving.

Maintenance


Lubricate the lock with graphite annually. Lubricate the ball bearing slides with grease twice annually. The casters do not require lubrication.




Rolling Cabinet

Assembly


When assembling the cart, please start from top to bottom.



1. Insert the handle tabs into the slots at the same side as the casters with brake.
 2. Insert a M6*12 hex bolt through a washer into each handle tab.
 3. Tighten all bolts securely.
- Side handle must be assembled at the same side as the casters with swivel brake.




1. Place the cabinet wheels up on a flat surface. Protect the paint by placing the packaging down first.
2. Insert the bolt into the spring washer, then the washer. Attach the caster to the mounting plate. Mount both swivel casters on the same side of the cabinet as the side handle.
3. Tighten all bolts by hand until the cart is assembled. Then, tighten the bolts using a wrench until you feel resistance. Do not over tighten.



To remove the drawer:

1. To remove drawers, release the retaining clip by pushing the lever up on one side and down on the other side simultaneously.
2. Then pull the drawer out.



To reinstall drawers:

To reinstall drawers, place on slide channels and slide drawer in completely.



Rolling Cabinet

Warranty

LIMITED ONE-YEAR WARRANTY

Should this product fail to perform satisfactorily due to a defect or poor workmanship within ONE YEAR from the date of purchase, return it to the place of purchase and it will be replaced free of charge. Incidental or consequential damages are excluded from this warranty.

For Repair Parts, call 1-800-323-0620

24 hours a day – 365 days a year





Figure X – Repair Parts Illustration for Model(s) 32H851


Repair Parts



Lock and key set, parts number: TTLK001G



Rolling Cabinet



Repair Parts List

Reference Number	Description	Part Number	Qty.
1.	Lock and key set	TTLK001G	1
2.	Keys (Please refer to the number on the key/lock for the last three digits.)	MGC01XXX	2
3.	Fixed Caster and Swivel caster with brake (For 32H882,32H883)	TT42PPG	1
	Fixed Caster and Swivel caster with brake (For 32H884,32H851)	TT52PPG	1