Accessories, continued

	Description	Catalog Number
	Hole Plugs	
10250TA7 	**Plug**— For unused holes—steel, painted gray (stainless steel, use **E30KT5**, see **Page V7-T1-206**)	**10250TA7**
	Tools	
10250TA95 	Octagonal 10250T (notched to fit over selector switch lever), E29 and E30	**10250TA95**
E22CW 	E22, E30, E34 and octagonal 10250T (will not fit over selector switch levers)	**E22CW**
10250TA96 	**Tool for Tightening Boots**— Used to install boot Catalog Numbers 10250TA3, A4, A10 and A25.	**10250TA96**
10250TA102 	**10250T, E34 Allen Wrench**— Used for removal of jumbo mushroom head.	**10250TA102**
10250TA74 	**Lamp Removal Tools**— For transformer type illuminated pushbuttons, push-pull and selector switches. Fits #12 lamp.	**10250TA74**
E30KV1 	For full voltage and resistor type illuminated pushbuttons, push-pull and selector switches and E30.	**E30KV1**
E29KLT 	Standard indicating lights. Fits #44, #755, #6S6 and #10S6.	**E29KLT**