


User Manual

AIR PURIFIER

Model No.: KJ410G-A01



- Please read this manual carefully before use.
- The company reserves the right to interpret the instructions.
- The appearance of the product is subject to the actual product.

■ SAFETY INFORMATION

Before Use

- Before connecting the plug to a wall socket, verify the correct mains voltage. Refer to the specifications on the rating label of the device.
- If the supply cord is damaged, it must be re-placed by the manufacturer, its service agent or similarly qualified persons to avoid a hazard. Do not repair the device by yourself.
- When cleaning or putting it away, switch off the device and always pull out the plug from the socket (pull the plug itself, not the lead) if the device is not being used and remove the attached accessories.

Usage Environment

- Never operate the device in a room where explosive gas may accumulate. Risk of explosion if solvent or gasoline leaks from paint and adhesive.
- Never place burning items (such as candles, cigarettes, or similar) near the device, otherwise there will be danger of damage or even fire.
- Never operate the device in a room with high air humidity, such as a bathroom, shower or swimming pool, as moisture can accumulate in the device and cause an electric shock.
- Never use any spray in the room.
- Never add aromatic oil to the filter.
- Operate the device only at room temperature between 0°C and 40°C.

In Use


- Operate the device only with the filter element inserted and the cover closed.
- Do not insert any items into the openings of the device.
- Never place the device directly next to ovens or other sources of heat.
- Do not hesitate to pull the plug if any bad smell released by the running device.
- Do pull the plug if need to remove the device. Notice of Cleaning
- Do not use any wire brush or other abrasive objects.
- Do not use any acidic or abrasive detergents.
- Always pull the plug before cleaning and maintenance.
- Clean the housing with a dry cloth, without additives.
- Never immerse the motor housing in water for cleaning. It could result in an electric shock or fire.

Warm Reminder


- In order to ensure your children's safety, please keep all packaging (plastic bags, boxes, polystyrene etc.) out of their reach.
- This device can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the device in a safe way and understand the hazards involved.
- Children shall not play with the device.
- Cleaning and user maintenance shall not be made by children without supervision.

■ PRODUCT DETAILS

Spare Parts



Air Purifier Device




Air Filter

(The filter is placed inside the device, please remove the packaging bag before use)




User Manual

Product Structure



■ OPERATION GUIDE

Schematic Diagram of The Control Panel



Once the device is powered on, it enters standby mode.



Power On/Off



"Wind speed" button, display the wind speed gear

- a. When you click this button repeatedly, you can switch between manual/automatic/sleep wind speed modes, which are gear 1, gear 2, gear 3, and gear 4, automatic mode, sleep mode.
- b. Automatic mode, automatically adjust the wind speed according to the air quality.
- The air quality indicator shows the PM2.5 air quality status in real time;
- c. Green light: excellent air quality Blue light: good air quality
Yellow light: average air quality Red light: poor air quality



"Timer" button, display the set time

When the digital tube displays PM2.5, touching this key will first display the current timing time (without time switching) and then each time you press it will switch the time once, a key beep, timing 1h, the digital tube lights up, press multiple times The timing key can cycle to select the timing time, (the digital tube displays the timing, and the PM2.5 value will be restored after 5S) 1h...2h 3h... 12h --h 1h...Cyclic switching ("--h" means no Timing, if it is in the state of setting timing power on, "--h" will not be displayed), after displaying 2S, it will enter the countdown state.

After the timer is complete:

- a. Scheduled shutdown: If it is on, it will shutdown at scheduled time.
- b. Timing power-on: If it is in the standby state, it will power on regularly.



"Child lock" button, turn on/off the child lock function

Long press this button for 2s to enter child lock mode, and long press this button for 2s again to exit child lock mode.



Long press the [ + ] key for 2s to enter the WIFI network pairing mode.




When the filter life expires, long press the [ + ] button for 2s, the filter life reset is completed.

■ FILTER REPLACEMENT


1. Shut Down and Cut Off the Power of the Device.

Note:


Turn off the purifier, the purifier is in standby mode, you need to unplug the power plug to cut off the power of the device.



2. Open the back cover, grasp the grip of the back cover and pull it out.



3. Take out the filter and wrap the waste filter in a garbage bag to prevent pollutants on the filter from falling into the room.




▲ Notice:

- a. Please dispose of the used filter as non-combustible garbage;
- b. The replacement cycle of the filter is about half a year (the replacement cycle of the filter varies greatly due to the use of the environment);
- c. When the filter indicator is red, it prompts to replace the filter.

■ FILTER REPLACEMENT



4. Adjust the direction of the new filter screen to correspond to the filter screen slot on the purifier, and install the filter screen; then grasp the filter cover clasp, and align the bottom of the filter cover with the groove at the bottom of the main unit before closing the door cover, and plug in the power cable to run.



▲ Notice:

- a. Please read carefully the filter replacement operation to ensure the purification effect of the purifier.
- b. Before cleaning the purifier system, unplug the power plug and cut off the power of the purifier system.
- c. Keep the inside of the purifier dry to prevent damage to the circuit.
- d. When the surface is dusty, use a vacuum cleaner to clean the surface dust, which can prolong the service life of the filter.

The top of filter



The bottom of filter

5. After the filter is replaced, please reset the filter reminder, press and hold the [⏻ + ⏪] key for 2s.

▲ Note:

The filter should be installed with the bottom face down.

■ COMMON TROUBLESHOOTING

If your air purifier is not working properly, please check the following before sending it for repair.

Phenomenon	Possible reason	Solution
1. The machine does not start.	a. The power plug is not installed. b. The filter cover of the machine is not installed in place.	a. Reinsert the power plug. b. Reinstall the filter cover of the machine and install it in place.
2. There is smell in the outlet.	a. There are many sources of pollution in the room. b. The filter is seriously polluted.	a. It is recommended to open the windows of the room for ventilation. b. Replace with a brand new filter.
3. The effect of dust purification is not significant. Improvement of air quality is not obvious.	a. The machine is not equipped with a filter. b. The machine is placed in a narrow place. Or there are obstacles nearby that affect the purification effect. c. The filter is too dirty.	a. Install the filter. b. Remove the blockage or change the location. c. Clean or replace the filter.
4. The running noise is too loud.	a. The installation may not be firm enough. b. There is debris in the machine.	a. Contact the after-sales service center. b. Remove debris.
5. The key of the main unit fails.	a. The child lock may have been opened.	a. After rotating the button to the child lock icon, press the Button for 2s to release child lock.
6. The filter can't fit in.	a. The filter is reversed.	a. Adjust the filter in the correct direction. Align the filter screen with the bottom groove, and then install it.

Error Code	Fault Description	Solution
E0	The filter cover is took off.	a. Close the door cover tightly; b. If you can't solve it, please contact customer service;
E1	The device is tipped or tilted.	Erect the machine normally;
EE	Filter life expires	a. Please replace the filter and reset: Reset operation: In the standby state, press the "⊕ + ⊖" button at the same time for 2s, the machine will beep three times, and the reset is successful.

▲ Note: If the fault cannot be rectified after the above inspection, please contact the repair shop or technical service center provided by our company's service center. Never disassemble and repair it to avoid danger and damage to the device.

