25-12-29

GLAHODEN

Achieve your dream garden with our love

Technical Specifications

Model No.	WH-30	WH-45B	WH-60	WH-90
Hose Length	30m/98	45ft/13.7	60ft/18	90ft/27.4
Working Pressure	12BAR	12BAR	12BAR	12BAR
Hose Diameter	12mm	12mm	12mm	12mm
Hose Material/Fitting Body	1/4" MP	1/4" MP	1/4" MP	1/4" MP
Lance Size	1/4"	1/4"	1/4"	1/4"

General Instructions

Note: Water no longer usable should not be disposed of with household waste but in an environmentally friendly way. Please consult where this is the case in your area.

Recycling packaging reduces the amount of waste that becomes material. Dispose of recyclable materials responsibly in the environment. Please recycle packaging waste. Rooftop cover.

Warranty Details

We provide lifetime customer service to customers who purchase GLAHODEN. Our core goal is to ensure all after-sale support and lifelong technical support. We offer solid guarantee of the entire technical chain, including service, from repair and replacement service for ensure for our future customer satisfaction. In the meantime, we offer free gross replacement service and quick replacement service for the first two years after purchase. We provide lifetime technical support, including technical support for better understanding of product's usage, installation, and all troubleshooting.

After-sale details

If you have any questions, please contact our customer service, please: **email: sales@GLAS.com**
and provide us corresponding video and photo number.

Unpacking

Glahoden makes every production item pass, in it certifies that our Retractable Garden Hose is lively or not. Because of the production process, water will be left in the hose. We recommend that you drain the water from the hose before the hose reaches Europe or the United States. Failure to do so could result in rusting and other issues.

Intended Use

The Retractable Garden Hose is manufactured with a high-quality hose. This ultra-durable, neatly flexible garden hose provides a semi-automatic retracting function. The retractable garden hose has a well-reconsidered bracket that allows for a 360°-180° range of motion, and the deflector tool that the hose is very length-adjustable. The hose is made of PVC and is also anti-kink. Unless included and sold separately, the product should provide you several good functions.

The Retractable Garden Hose is designed for home water applications using and water only. Please note that the Retractable Garden Hose has not been designed for use in construction, trade or industrial applications.

This appliance is the used only for household garden purposes. Any other use is deemed to be a case of misuse. The user/operator, and not the manufacturer, shall be liable for any damage or injury resulting from such cases of misuse or improper handling caused after the intended purpose.

Please read and familiarize yourself with this user manual before using the Retractable Garden Hose.

IMPORTANT Please check with your local government body or local water provider for any active water restrictions in your area.

Description of Symbols

The warning signs on the product and in this user manual may describe following symbols.

	Read and observe the user manual. Before using the product, read the user manual.
	Danger, risk of personal injury, loss of life or damage to the device in case of non-observance of the instructions in the manual.
	Non-potable water.

Operation

When you have finished watering, turn off the water. As a reminder, the pressure inside is extremely high. WARNING!!! Please slowly and your equipment/tools may be injured and provoke the very active water restrictions in your area.

1. The hose reel has been equipped with a child lock mechanism. When the hose is pulled out to the desired length, and when you stop pulling, the hose will automatically stop.

WARNING: When the hose is retracted to a set length that the warning indicator can be seen (approx. 1-2 ft before the end of the hose), the hose reel will slow down automatically and will not damage the internal retraction (only ver)

2. To start watering, turn on the water at the tap.

3. When you have finished watering, turn off the water. At the point where the pressure in the hose gets to remaining low hose.

4. To engage the automatic hose reel, gently the hose a third (that is pulling and release it to retract pull the hose back to the reel. The hose will stop automatically when it reaches the hose gun.

NOTE: In order to protect the hose safety, ensure you keep the hose reel in a dry place and avoid exposure to direct sunlight. Avoid leaving the hose gun in the hose, and leaving it for long may result in pressure injury.

WARNING!!! Do not pull the hose in the direction of which the hose is retracting. Instead, allow the self-tapping mechanism to feed the hose slowly into the internal retracting.

WARNING!!! Wind hose and handle tightly and slide back. It is strongly recommended that you remove the hose gun from the hose reel when not in use. Failure to do so may result in the hose gun being damaged. Warning: Pull and allow the self-tapping mechanism to retract. Wind hose carefully and tightly.

Scope of Delivery

A. 1 x Wall Mounting
B. 1 x Hose Reel Rooftop Cover
C. 1 x Lance
D. 1 x Hose Gun
E. 1 x Connector
F. 1 x Tap Connector
G. 1 x Deflector
H. 1 x Hose
I. 1 x Instruction Manual

Product Components



A	Spray Nozzle	G	Spray Handling
B	Hose Gun	H	Wall Mounting Bracket
C	Hose Tap	I	Locking Knob
D	Hose Reel Housing	J	Hose

TABLE OF CONTENTS

GENERAL INTRODUCTION 01
- Intended Use 01
- Intended Use 01
- Description of Symbols 01
- General Safety Instructions 02

WHAT'S IN THE BOX 02
- Scope of Delivery 02
- Product Components 03

HOW TO INSTALL 04
- Tools Required for Assembly 04
- Fix the Bracket to a Wall 04
- Install the Hose Reel to the Bracket 05
- Assemble the Hose to Water Tap 05

START TO USE 06
- Operation 06

PROBLEM GUIDE 07
- Troubleshooting 07
- Cleaning and Maintenance 07

TECHNICAL SPECIFICATIONS 08

DISPOSAL INSTRUCTIONS 08

2-YEAR WARRANTY 08
- Warranty Details 08
- After-sales Details 08

General Safety Instructions

WARNING! Read the entire user manual carefully. Understand and follow all safety instructions. Failure to observe safety hints. Failure to follow the warnings and instructions may result in serious injuries.

Save all warnings and instructions for future reference.

Please read the instructions carefully! Please ensure people who follow instructions relevant to the hose pressure are aware of the following:

- Do not allow the hose to freeze! precaution: If the hose deflates the hose. Ice can press your inside fitting, causing the hose to burst. Do not use the hose in freezing conditions.
- Do not open the hose reel housing. The internal spring mechanism is under quite massive pressure. Dangerous if released. If opening or disassembled occurs, please ensure the other safety support is in place and secure.
- Do not leave water standing in small hose lengths under pressure when not in use.
- Always turn the water off before the hose after use.
- Do not use the hose for other purposes than watering.
- Do not place hose on the hose reel housing. Doing so may damage the housing or the wall mounting bracket.
- Do not allow children or pets allowed to operate or play with the retractable garden hose.
- Cases of children and pets allowed to hose and play and hose play, when unwinding and rewinding, the hose may be pulled out of the hand, and the hose may be pulled, and the hose may be pulled out of the hand and injure or damage the hose and the reel.
- Do not allow children to play with the hose. Remember, everyone. Pressure hose hose before unwinding the hose. Hose can be fatal.
- Do not allow the hose to be exposed to sunlight or very low temperatures for prolonged periods of time. Do not place the hose in direct sunlight. Do not place the hose in direct sunlight. Long-term exposure to the hose causes flexibility to decrease, difficult to retract.
- Do not use any chemicals in conjunction with the hose such as solvents, acids, spray bottle cards, etc. Do not use the hose in conjunction with any chemicals, solvents, or acids.
- Ensure the hose reel housing is a stable and not installed on a place or a wall, to prevent the hose reel housing from falling and causing injury.
- Do not place the hose reel on a place or a wall, to prevent the hose reel housing from falling and causing injury.
- Before you fix the bracket, ensure the wall is strong enough, and the wall can support the hose reel. Ensure the hose reel is firmly installed on the wall. Failure to do so may result in the hose reel falling and causing injury