

01 / Usage and warranty of atomized fireplace

About the atomization fireplace

Using atomization technology combined with special physical phenomena to create a realistic flame effect, an ultrasonic ion atomizer is built-in, and a blower is used to blow out water vapor. The light illuminates the water vapor to form the flame effect in front of us.


Installation and use of atomized fireplace

The 3D atomized fireplace is laid flat inside the groove, and sockets need to be reserved inside the groove.

Warning


- 1 When adding water, it is necessary to have someone watching from the side to avoid water splashing out and damaging electrical components.
- 2 This product relies on an ultrasonic atomizer to produce flames. It is the best to add purified water or reversed osmosis water into the water tank. Please drain the water and keep it dry if you don't use it for a long time.
- 3 If you need to move/move the machine, remember to first cut off the power, drain the water in the water tank, and then carefully test the temperature of the machine panel with your hands before moving/moving the machine.

02 / Touch Pad




- Wi-Fi
- Flame Level (F1-F5)
- Dimmable
- Power
- Timer
- Water Output
- Water Level
- Water Input

03 / Remote control



Monochrome Remote Control



RGB Remote Control


04 / Remote Control Pairing Instruction

- 1 Make sure the power cord is unplugged;
- 2 Put the battery in the remote control, press and hold the alarm timer button (⌚)

At the same time, plug in the power cord.
Please hold the timer button (⌚) until the touch pad shows "oU", which means pairing is successful.

05 / Mobile APP connection method (Only applicable when the fireplace you purchase has the APP function)

- 1 Download the "TUYA" APP;
- 2 Plug the power cord and turn the fireplace; open "TUYA" APP to add equipment (upper right corner);
- 3 Click the found device to enter your WIFI name and password, wait for about 1 minute to add the device, click the bottom "completed"; (only work in 2.4G, instead of 5G)
- 4 Enter the operation interface to be controlled according to your needs.
- 5 After successfully connecting the fireplace, you can click on any color on the light spectrum to change it.




Reset WIFI

- 1 Plug in the power cord and turn off the fireplace.
- 2 Press and hold the WIFI button on the touch pad until it “beeps” and flashes, then the WIFI is reset successfully so you can switch to another WIFI.

Share The Device With Your Family

- 1 Plug in the power cord and enable the “Bluetooth” on your phone.
- 2 Open TUYA APP and click the fireplace and go to  (on the right upper corner), find “share device”.
- 3 Ask your family to click the link you shared and go to TUYA APP, accept the fireplace. Then your family will be able to control the fireplace by the TUYA APP.



06 / Intelligent water control

Automatic water addition

Connect the black water hose to “Auto Feed” inlet and press the water addition button to automatically add water.



Water connection direct(Only applicable when the model you purchase has this function)

Connect the white water pipe to the bottom of the fireplace and faucet for direct water supply.



II- Automatic water addition.

I- Water connection direct.

O- No water can be added.



Add water: When the machine is turned on and voice prompts water shortage, then press  on the touch pad to add water.

Drain water: When you need to drain the water, connect the water hose to the water outlet  of the panel. Press and hold  on the touch pad for 3 seconds to drain water.

 Real time display of water level:

- Low water level: flashing and voice prompts
- Middle water level(during use): not shown, no voice prompts
- Full water level: flashing for seconds and disappear, voice prompts

Notice:

The fireplace will reach the best flame effect after running for 15 minutes.

07 / Warranty Description

Promise

- 1 All products sold by our factory have a warranty period of two years, with free maintenance during the warranty period (excluding wear and tear parts, faults or damages caused by human factors or uncontrollable natural phenomena).
- 2 After receiving the repair notice, solve the problem within seven working days (except for special circumstances).

Users can inquire about technical issues through after-sales mail and receive clear solutions.

- 4 In case of performance failure during normal use, our company promises the above warranty services. Unless otherwise specified in applicable national laws and regulations, our company will comply with relevant laws and regulations.
- 5 During the warranty period, repair services will be provided at your expense for the following situations:
 - (1) Damage caused by human or uncontrollable natural phenomena;
 - (2) Malfunction or damage caused by improper operation;
 - (3) Due to the modification of the product.

Atomized Fireplace Instruction

